



ON / OFF

Turns both DIRECTV® Receiver and TV ON or OFF at the same time. (Remote must be programmed for TV. HD DVR Receiver still records when off).

GUIDE

Press once for On-Screen GUIDE.
Press twice for programming grouped into categories.

RECORD

RECORD program now playing or highlighted in the On-Screen Guide
Press twice to record the entire series.

RED CIRCLE BUTTON

Press to delete recorded shows from your playlist.
Access SCOREGUIDE™ while viewing any sports channel.

VOL

Increase or decrease the VOLUME level.

MUTE

MUTE the sound.

REPLAY

REPLAY previous six seconds.
Press and hold to jump back to the beginning of a recorded program.

REWIND

REWIND at increasing speeds—press up to four times.
Press and hold to jump to previous tick mark.

Jump back 12 hours while viewing the On-Screen Guide.

PLAY/PAUSE

PLAY current program.
Press once while program is playing to PAUSE.

Press and hold while recording is playing for slow motion.

DASH

Press for Guide Options while viewing On-Screen Guide.

Press for playlist options while viewing playlist.

Press to display last 6 digits of receiver ID, Satellite signal type (SWIM or Multiswitch) and Internet status.

MENU

Display the MENU.

LIST

Display the LIST of your recorded programs.

ARROWS

Press to move up within a menu.
Press to move down within a menu.
Press to move right within a menu.
Press to move left within a menu.
Press to go back within menus.

EXIT

EXIT the menu and return to previous channel viewed.
Stop playback while viewing recorded content.

SELECT

SELECT item highlighted on screen.

INFO

Display INFORMATION about the program now playing or highlighted in the On-Screen Guide.

CH

Change TV CHANNELS.
Scroll a full page while viewing the On-Screen Guide.

PREV

Return to PREVIOUS channel viewed.

ADVANCE

ADVANCE 30 seconds.
Press and hold to jump ahead to the end of a recorded program.

FAST-FORWARD

FAST-FORWARD at increasing speeds—press up to four times.
Press and hold to jump to next tick mark.
Jump ahead 12 hours while viewing the On-Screen Guide.

ENTER

Press for Mini Guide while viewing your program and dismiss with EXIT.
ENTER also replaces TV INPUT button: To cycle through the equipment connected to your TV, press and hold for three seconds until LED light at top turns green. Then scroll through inputs by pressing ENTER again.

